


The original 120/220VAC powered illuminator circuitry is completely replaced by the Nanodyne equipment which is powered by a universal input wall plug power supply with low voltage DC output.

The original circuitry may be left in place, or removed as it is no longer used.

Regardless whether the original circuitry is left in place or removed, be sure there is no possibility of electrical hazard in case an unfamiliar user connects power to the old high voltage AC input.

We recommend removing the power leads (usually one black and one white wire) from the AC input connector. They should be cut short so there is no possibility they could contact the power inlet, or insulated with heat shrink tubing or electrical tape.



After installation of the Nanodyne illuminator, there should be no power connections left in place to the AC power inlet. The ground wire should be left connected.

Han-Seung Yang	6/11/2021		
PN 10472 Olympus BX41 Installation Instructions	and	l 45	REV 6
SHEET	2	OF	8

© Copyright 2021 Nanodyne Measurement Systems. Document authorized for installation of Nanodyne equipment only. www.nano-dyne.com Wayne Bonin 651-323-8592

igsim 3


В

Nanodyne Replacement Illuminator for Olympus BX41/45 Microscope Installation Instructions: Step 2. Remove Covers and Intensity Adjust Pot




The scope used for these photos was a boneyard unit with parts scavanged from it.

(FYI if you wonder about missing parts)



Remove the back and bottom covers from the microscope (not shown). Loosen the set screw in the adjustment knob with the 1.5mm hex key and remove the knob from the pot.



Disconnect the Adjustment pot from the cable as shown above, remove the nut holding the pot in place with an 11mm socket, and remove the original pot.


Han-Seung Yang 6/11/2021 PN 10472 Olympus BX41 and 45 REV Installation Instructions SHEET 3 OF 8

© Copyright 2021 Nanodyne Measurement Systems. Document authorized for installation of Nanodyne equipment only. www.nano-dyne.com Wayne Bonin 651-323-8592

Nanodyne Replacement Illuminator for Olympus BX41/45 Microscope Installation Instructions: Step 3. Install New Pot-Cable Assembly







Install the new pot-cable assembly. Remove the nut from the pot. Do not attempt to remove the washer. It is glued in place. It was designed specifically for this microscope to prevent the pot from rotating while tightening the nut. Place the pot as shown in the upper left photo (photo 3a), and install the nut with a 10 mm socket. Tighten securely by hand without tools other than the socket.


Han-Seung Yang 6/11/2021
PN 10472 Olympus BX41 and 45 REV Installation Instructions 6
SHEET 4 OF 8

© Copyright 2021 Nanodyne Measurement Systems. Document authorized for installation of Nanodyne equipment only. www.nano-dyne.com Wayne Bonin 651-323-8592


Photo 3b

2

Nanodyne Replacement Illuminator for Olympus BX41/45 Microscope Installation Instructions: Step 4. Replace Pot Knob and Secure Cables



Re-install the knob on the pot with the 1.5mm hex key.




Secure the cables as shown above with the 3 tie wraps, to keep the cables out of the moving parts of the microscope, and the optical path from the illuminator.

Han-Seung Yang 6/11/2021 PN 10472 Olympus BX41 and 45 REV

Installation Instructions SHEET 5 OF 8

© Copyright 2021 Nanodyne Measurement Systems. Document authorized for installation of Nanodyne equipment only. www.nano-dyne.com Wayne Bonin 651-323-8592

Nanodyne Replacement Illuminator for Olympus BX41/45 Microscope Installation Instructions: Step 5. Attach Nanodyne Illuminator, Connect and Secure Pot Cable



NOTE: The photo shows an obsolete version.

In the current version the pot cable (red, blue and black wires) plugs into the botton of the illuminator.

See sheet 7 for details.

Plug the Nanodyne illuminator into the microscope port and connect the pot cable.

Secure the pot cable with the 3M VHB tape provided.

Han-Seung Yang 6/11/2021
PN 10472 Olympus BX41 and 45 REV Installation Instructions 6
SHEET 6 OF 8

© Copyright 2021 Nanodyne Measurement Systems. Document authorized for installation of Nanodyne equipment only. www.nano-dyne.com Wayne Bonin 651-323-8592

Nanodyne Replacement Illuminator for Olympus BX41/45 Microscope Installation Instructions: Pot Cable Connection Details


Connect the plug at the end of the Pot Cable Assembly to the mating socket of the illuminator, as shown in the pictures on this page. NOTE THAT THE PLUG IS KEYED TO ONLY GO INTO THE SOCKET ONE WAY, AS SHOWN.

Partially insert the plug into the mating socket of the illuminator by holding the wire next to the plug with your finger (photo 2).


Use your fingernails, if you have them, or tools like a tiny screwdriver or tweezers pushing on the side of the plug to fully insert it (photo 3).


The socket cannot be fully engaged by pushing on the wires, as the wires would just collapse.

To disconnect it if needed, pull the wire straight out by firmly gripping the black heat shrink tubing.



Partly Inserted






Han-Seung Yang	6	5/11/	20	21
PN 10472 Olympus Installation Instructio		and 4	45	REV 6
S	HEET 7	7 ()F	8

© Copyright 2021 Nanodyne Measurement Systems. Document authorized for installation of Nanodyne equipment only. www.nano-dyne.com Wayne Bonin 651-323-8592

4 3 \triangle 2

Nanodyne Replacement Illuminator for Olympus BX41/45 Microscope Installation Instructions: Step 6. Replace the Covers and Install the AC Power Blocking Plug





Replace the microscope covers, insert PN 10736 rubber plug into AC receptacle (red circle) to deter attachment of unneeded AC power cord, plug in the power supply, and the installation is complete.

Note: Installation of PN 10736 rubber plug is shown below.









В

Han-Seung Yang 6/11/2021

PN 10472 Olympus BX41 and 45 REV Installation Instructions 6 SHEET 8 OF 8

© Copyright 2021 Nanodyne Measurement Systems. Document authorized for installation of Nanodyne equipment only. www.nano-dyne.com Wayne Bonin 651-323-8592

2

1